

MAXIGAS

Nitrogen Gas Generators

The cost-effective, reliable and safe solution for medium to large nitrogen requirements.

MAXIGAS nitrogen gas generators from Parker produce nitrogen gas from compressed air and offer a cost-effective, reliable and safe alternative to traditional nitrogen gas supplies such as cylinder or liquid.

Nitrogen is used as a clean, dry, inert gas primarily for removing oxygen from products and/or processes.

MAXIGAS provides an on-demand, continuous source of nitrogen gas which can be used in a wide range of industries such as food, beverage, pharmaceutical, laboratory, chemical, heat treatment, electronics, transportation, oil and gas and laser cutting.



Contact Information:

**Parker Hannifin Ltd
Industrial Division**

Dukesway, Team Valley Trading Estate
Gateshead, Tyne and Wear
England NE11 0PZ

Tel: +44 (0)191 402 9000

Fax: +44 (0)191 482 6296

Email: gasgen@parker.com

www.parker-separation.com

Features:

- **Can operate from a standard factory compressed air supply**
- **Delivers 5% down to 10ppm oxygen content, without the need for any additional purification**
- **Available in 7 models offering varying flow rates and purities**
- **Automatic economy mode**
- **Built-in oxygen analyser for continuous purity monitoring**
- **Digital and analogue outputs for remote monitoring**
- **Alarm capabilities**
- **User friendly control interface**
- **Compact design**
- **Modular concept**

Benefits:

- **Up to 90% cost savings***
Typical capital pay-back is achievable within 12-24 months
- **Energy savings**
Low air consumption provides greater energy efficiency
- **Convenient and safe**
The easy to use system is simple to install, requires minimal maintenance and eliminates safety hazards associated with traditional gas supplies
- **Space saving design**
The compact design means the system demands less floor space
- **Flexible multi-bank option**
The modular concept means the generators can be multi-banked if required
- **Reduced carbon footprint**
The elimination of cylinder deliveries and transportation means carbon footprint can be reduced

* Typical cost savings achieved in comparison to cylinder or liquid supply



ENGINEERING YOUR SUCCESS.

Product Selection

Performance data is based on 7 bar g (100 psi g) air inlet pressure and 20° - 25°C (66° - 77°F) ambient temperature. Consult Parker for performance under other specific conditions.

Oxygen Content												
Model	Unit	10ppm	100ppm	250ppm	500ppm	0.1%	0.5%	1.0%	2.0%	3.0%	4.0%	5.0%
MAXIGAS104	m³/hr	2	3.2	6.7	8.1	9	14.1	17.8	22	25.8	29	32.2
	cfm	1.2	1.9	3.9	4.8	5.3	8.3	10.5	12.9	15.2	17.1	19.0
MAXIGAS106	m³/hr	3	4.8	10	12.1	13.4	21.2	26.6	32.8	38.7	43.5	48.3
	cfm	1.8	2.8	5.9	7.1	7.9	12.5	15.7	19.3	22.8	25.6	28.4
MAXIGAS108	m³/hr	3.9	6.4	13.4	16.2	18	28.3	35.5	43.8	51.6	58	64.4
	cfm	2.3	3.8	7.9	9.5	10.6	16.7	20.9	25.8	30.4	34.1	37.9
MAXIGAS110	m³/hr	4.9	8	16.8	20.2	22.4	35.3	44.4	54.7	64.5	72.5	80.4
	cfm	2.9	4.7	9.9	11.9	13.2	20.8	26.1	32.2	38.0	42.7	47.3
MAXIGAS112	m³/hr	5.9	9.6	20.1	24.2	26.8	42.4	53.3	65.7	77.4	87.1	96.5
	cfm	3.5	5.7	11.8	14.2	15.8	25	31.4	38.7	45.6	51.3	56.8
MAXIGAS116	m³/hr	7.9	12.8	25.5	30.7	34	53.7	67.5	83.2	98.1	110.3	122.3
	cfm	4.6	7.5	15.0	18.1	20.0	31.6	39.7	49	57.7	64.9	72.0
MAXIGAS120	m³/hr	9.8	16	30.9	37.2	41.2	65	81.7	100.7	118.7	133.5	148
	cfm	5.8	9.4	18.2	21.9	24.2	38.3	48.1	59.3	69.9	78.6	87.1

m³ reference standard = 20°C, 1013 millibar(a), 0% relative water vapour pressure.

Technical Data

Ambient Temperature Range	5 - 50°C
Nitrogen Outlet Pressure	up to 13 bar g
Air Inlet Pressure Range	6 to 15 bar g
Air Inlet Quality	-40°C
Pressure Dewpoint	<0.1 micron
Particulate	<0.01 mg/m³
Oil	
Electrical Supply	85V-264V AC/ 50Hz - 60Hz /1ph
Port Connections	G1
Air	G1/2
Nitrogen	

Weights and Dimensions

Model	Height (H)		Width (W)		Depth (D)		Weight	
	mm	in	mm	in	mm	in	kg	lb
MAXIGAS104	1894	76	550	22	692	28	336	741
MAXIGAS106	1894	76	550	22	861	34	394	869
MAXIGAS108	1894	76	550	22	1029	41	488	1076
MAXIGAS110	1894	76	550	22	1198	48	582	1283
MAXIGAS112	1894	76	550	22	1368	55	676	1490
MAXIGAS116	1894	76	550	22	1765	71	864	1905
MAXIGAS120	1894	76	550	22	2043	82	1052	2319

Also available, MIDIGAS PSA technology in addition, NitroSource, Nitroflow Basic, LP and HP membrane technology. To ensure the best solution is selected, please contact Parker.

For information on extended warranty and preventative maintenance contract availability, please contact your local sales office or visit www.parker-separation.com

©2009 Parker Hannifin Corporation. All rights reserved.

Catalogue: 174004704
09/09 Rev.03



ENGINEERING YOUR SUCCESS.